

## FARBEN SHINE MASK DC Chrome Tanning Auxiliary

Appearance	: Yellowish liquid
Characteristics	: Mixture of dicarboxylicacid
Concentration (%)	: 41,0 ± 1,0
pH Value (10 % in water)	: 5,0 - 6,0

# **PROPERTIES AND APPLICATION :**

-It accelerates the formation of the chromium complexes using in chrome tanning. Thus, receiving chromium by the skin increases significantly. -It provides homogeneous chrome distribution. Thus allows smooth dyeing of the skin easier.

-Because of good fixation effect of the product, moving away chrome from the skin becomes less in retanning and washing of the shaved skins. -It is used in the basification step to increase chromium intake and fullness of the skin.

#### Recomended usage rates:

In basificationstep	0,5 – 1,0 %
Chromefixation	0,5 – 1,0 %
Tanningofgoatleathers	0,5 – 1,0 %
Retanningstep	1,0 %
Sheepandlambskinsinsuedetanning	1,0 g/L

## STORAGE :

In a cool and dry place in original packaging, can be stored for a period of one year. Product must be protected from excessive heat and cold.

## PACKAGING:

120 kg drums.

Technical information and recommendations contained herein, is reliable, but conditions and methods of use of our products are beyond our control notimply any warranty. We recommend to use to our customer after identified our products and the suitability of proposals of use. Tips on the use of our products be interpreted in terms of encouraging infringement of patent rights of others.