

### FARBEN SHINE ENZYME H Concentrated Enzyme for Use In An Acid Medium

Appearance	: White fine powder packed in small bags of 1 each one.	kg.
Characteristics	: Mixture of various proteolytic enzymes, activating agents and inert supports.	

# **PROPERTIES AND APPLICATION:**

-It is suitable for leather treatment in an acid medium for example pickled skins, wet blue etc...

-It eliminates insufficient soaked, limed or bated zones in the skins. -It imparts an excellent degree of softness to the leathers structure, by hydrolysing fiber substances, particularly very compact goatskins. -It eliminates chrome stains, uniforming their distribution.

### Recomended usage rates:

Depend upon the treatment method and leather type; 0,5 – 3,0 % (on shaved weight) The bath pH=5,0 – 6,0 The bath temperature =50 – 60  $^{\circ}\mathrm{C}$ 

Inpickleandfur-suedeapplication 1,0 – 1,5 g/L

# STORAGE :

In a cool and dry place in original packaging, can be stored for a period of one year. Product must be protected from excessive heat and cold.

# PACKAGING:

1 kg plastic drum.

Technical information and recommendations contained herein, is reliable, but conditions and methods of use of our products are beyond our control notimply any warranty. We recommend to use to our customer after identified our products and the suitability of proposals of use. Tips on the use of our products be interpreted in terms of encouraging infringement of patent rights of others.